

Cellular Shade Installation Instructions

Tools you will need:

Measuring Tape
1/4" Magnetic Nut Driver
Cordless Drill
Screwdriver
Ladder/Step Stool

Hardware you will receive

Cell Shade
Installation Brackets
Mounting Screws
Cord Cleat
Cord Cleat Screws




Blind installation


Hold the installation bracket in place 3/4" back from edge of drywall.



With mounting screw already in magnetic driver, attach bracket. Use two screws for each bracket. Repeat for second bracket on opposite side. If cell shade width is over 47" use third bracket provided for center of shade.



Making sure the cell shade is facing towards the interior of house, an indicator is the pull cord is accessible, place headrail up to brackets with the top of headrail angled towards the top clip of brackets. Insert the front of brackets into the slot of the headrail, and once in place, push the rest of the headrail up and back towards the back of bracket until it latches on to the bottom of the headrail. Check bottom latches of brackets to make sure they were secured.



Cord cleat installation

Find desired location at side of window for cord cleat, and mark. With a screwdriver, attach the cord cleat to the wall.



Operating your new cell shades

Corded shades come with 1 pull cord for operating. Pull the cord away from window to raise the fabric shade from the down position, and to lock in place at any desired position. To release from the "locked" position, pull cord toward center of window.



Cordless can be operated simply by gently pulling down or lifting up on the bottom rail to the desired height.

Top down/bottom up operates similarly to the single corded shade. One side raises or lowers the shade off of the sill and the other raises or lowers the shade from the top of the shade.

Care and cleaning of your cell shades

Installed shades should be dusted regularly with a soft, clean cloth, feather duster or lightly vacuumed with a soft brush attachment. Complete immersion is not recommended unless shade is badly soiled. If shade is immersed in water, make certain that all hardware components are thoroughly dried immediately after rinsing. Drain any excess water from fabric and raise shade to set pleats. Lower shade until fabric is completely dry.