

Custom Arch Installation Instructions

Tools you will need:

- Level
- 15/8" screws
- Cordless drill
- #2 drill bit
- Screwdriver
- Ladder/step stool

Hardware you will receive:

- Arch
- Screw cover, buttons

LWC custom arch installation

Place arch over window evenly spacing fans from sides of window sill. Screw one bottom corner of arch to wall while holding in place.



Place your leveling tool on bottom of arch to level the entire piece before screwing opposite side of arch. Once the arch is level and attached, screw remaining positions on the arch. Place provided screw cover buttons over holes.



Care and cleaning of your custom arch

Use an electro-static or feather duster to clean thoroughly. Use lengthening attachment if arch cannot be reached. Do not get arch wet.

