

Vertical Installation Instructions

Tools you will need:

Measuring Tape
Step Stool
Cordless Drill
¼" Magnetic Nut Driver
Ladder/Step Stool
Level

Hardware you will receive:

Weighted Laser Guide
4" L-Brackets
L-Bracket Screws
Vertical Headrail Clips
Laser Guide Screws
Valance Clips
Valance
Headrail Clip Fasteners (nut & bolt)
Headrail
Vertical Vanes



Vertical blind installation

Locate total height of vertical. Using measuring tape, measure approximately ½" greater than total height of vertical and mark on wall above left frame of window.

**Special note: Measure ½" greater over carpeted floor and only ¼" greater over tile floor*

Repeat previous step for the right side of window frame. Using the same step again, evenly space remaining number of brackets between right and left bracket until complete.



Repeat for all brackets. Next place an L-bracket on your wall marking so that it shows through the top hole of the L-bracket and fasten with the provided L-bracket screws. (Two per bracket)

Orient headrail so that the "open" position lies opposite glass door handle or any opening latches. Place front of vertical headrail into clips and press up until headrail clips "snap" into place. Attach vertical vanes by placing decorated side in the same direction as the shorter end of the plastic vane clips.



Attach valance clips by placing the bottom slot of the clip to the top edge of the headrail and push the back of clip down towards the headrail until it snaps into place. The curved portion of the clip should be facing the wall.



Repeat steps while evenly spacing all valance clips. Place top of valance into the slots of all clips. Valance is attached when valance returns touch the wall. Push the buttons of the weight together to release top from the bottom.

Take the looping cord and put through top portion of the guide. Reconnect the bottom weighted portion with the top and cord. Connect entire weight assemble to wall if desired with provided screw.



Care and cleaning of your vertical blinds

Clean soiled blind surfaces with a mild soap solution. Do not use steam, hot water, bleach, or any abrasive or solvent-based cleaners.